




# Parts List for Service Kits



#	Part	Part #
7	Screw adjuster assy.	880-144-01
6	Nut 1/4-20 hex jam	11021-03
5	Washer 1/4 int. lock	11163-04
4	Dust seal	880-142-01
3	Retaining Ring	11090-04
2	Spool & o-ring assy.	880-258-01
1	Spring	880-148-01



#	Part	Part #
7	Pin 1/8 x .38 roll	10004-08
6	Roller	881-119-01
5	Dust seal	880-142-01
4	Retaining Ring	11090-04
3	Screw #62-32 x .62 self sealing	11477-01
2	Spool & o-ring assy. (roller)	881-139-01
1	Spring	880-148-01



#	Part	Part #
8	Nut 5/16-18 hex	11179-05
7	Washer 5/16 int. lock	11163-05
6	Actuator - offset (duckfoot)	881-120-01
5	Washer 5/16 plain S.S.	11275-06
4	Dust seal	880-142-01
3	Retaining Ring	11090-04
2	Spool & o-ring assy. (duckfoot)	881-122-01
1	Spring	880-148-01